

Duropal Benchtops

Cleaning Instructions

There's nothing easier than cleaning and caring for Duropal Benchtops.

A major advantage of Duropal Benchtops is that the HPL surface makes cleaning so simple.

Usually a moist cloth is sufficient, but use washing-up liquid to get rid of any grease.

Stubborn dirt can be removed with an organic solvent such as methylated spirits or alcohol.

Brushes with hard bristles (but not wire brushes) may also be used.

Light stains/dirt	Cleaning: Dry or damp paper towels, a cloth or sponge.
Normal stains/dirt e.g. fat, oil and dirt particles, fingermarks, lime deposits, rust, juice, coffee, tea, wax, blood, universal marker etc.	Cleaning: With a cloth or soft nylon brush and washing powder, soft soap, toilet soap or washing-up liquid. If necessary, leave for a while and then rinse thoroughly with clean water.
Heavy stains/dirt e.g. discolouration through long exposure to tea, coffee, fruit juice etc.	Cleaning: With washing powder and household bleach (but do not repeat too often).
E.g. lead pencil, felt-tip pens, marker and ball-point pens, lipstick, crayons, wax, shoe polish, nicotine, nail varnish.	With an organic solvent such as acetone (nail varnish remover), methylated spirits, petroleum spirit, perchloroethene. Read the manufacturer's instructions carefully!
e.g. paint (water or solvent based paints, two-component paints, spray paints), varnish stains, printing ink	With water or an organic solvent. Remove two-component paints immediately.
e.g. adhesives (water-based, dispersion)	With water or an organic solvent.
E.g. two-component adhesives, urea resin, melamine, phenolic resin.	Remove immediately. Do not allow to harden!

